
+12v
-12v
TFR1
Tactile Led Switch 6x6x7
LED1
3ARB9HCB
LED2
3ARB9HCB
R4
150Ω
R3
150Ω
LED10
3ARB9HCB
LED9
3ARB9HCB
DTO1
Tactile Led Switch 6x6x7
R6
150Ω
MENU1
PROC1
ENT1
R1
150Ω
MENU2
PROC2
ENT2
R2
150Ω
MENU3
PROC3
ENT3
Tactile Led Switch 6x6x7
R5
150Ω
MENU4
PROC4
LED3
3ARB9HCB
VOL1
PEC11R-4015F-S0024
NAV
EC11EBB24C03
HDG
PEC11R-4015F-S0024
ALT
EC11EBB24C03
U1
ArduinoMegaPro
VOL2
PEC11R-4015F-S0024
COM1
EC11EBB24C03
CRS/BARO1
EC11EBB24C03
NAV_JOY1
RKJXT1F42001
FMS1
EC11EBB24C03
TFR2
Tactile Led Switch 6x6x7
R13
150Ω
LED18
3ARB9HCB
LED17
3ARB9HCB
R12
150Ω
LED16
3ARB9HCB
LED15
3ARB9HCB
LED12
3ARB9HCB
R11
150Ω
LED8
3ARB9HCB
LED7
3ARB9HCB
LED6
3ARB9HCB
R10
150Ω
LED4
3ARB9HCB
LED5
3ARB9HCB
DTO2
Tactile Led Switch 6x6x7
R9
150Ω
FPL1
Tactile Led Switch 6x6x7
CLR1
Tactile Led Switch 6x6x7
3ARB9HCB
LED11
R8
150Ω
MENU5
Tactile Led Switch 6x6x7
PROC5
Tactile Led Switch 6x6x7
ENT4
Tactile Led Switch 6x6x7
R7
330Ω
LED13
3ARB9HCB
LED14
3ARB9HCB
R14
150Ω
SW1
Tactile Led Switch 6x6x7
SW2
Tactile Led Switch 6x6x7
SW3
Tactile Led Switch 6x6x7
R15
150Ω
SW6
Tactile Led Switch 6x6x7
SW5
Tactile Led Switch 6x6x7
SW4
Tactile Led Switch 6x6x7
R16
150Ω
SW9
Tactile Led Switch 6x6x7
SW8
Tactile Led Switch 6x6x7
SW7
Tactile Led Switch 6x6x7
R17
150Ω
SW12
Tactile Led Switch 6x6x7
SW11
Tactile Led Switch 6x6x7
SW10
Tactile Led Switch 6x6x7
U2
ArduinoMegaPro
TITLE:
Sheet_1
REV: 1.0
Company: Your Company
Sheet: 1/1
Date: 2023-05-16
Drawn By: 737diysim
嘉立创EDA